


## Analog Sensor and Switch



Tiva is 5V tolerant, so it's fine to use these 5V sensors' outputs.